





CREATOR

31048




LEGO.com/creator








1x

1





2






2x



2x

3






1x





1x

4





5





1x




1x




1x

6





1x



2x

7





8





2x



4x

9



1



2

2x





1x

10





1x



1x



2x


11





12





13





14





2x



1x



2x



1x

15





1x



1x




1x

16





17






18



19





3x



1x



2x

20





21



22

6x
6x

6x





23






4x

24







25



26



27





1x




1x



1x

28





29





3x
3x


30





31





32






2x



2x

33





34







1x

35





36






1x




1x

37

1



2



2x



38





39






3x

40






1x



1x

41





1x

1x

2x

42





3x




1x



2x

43






1x



1x

44



45



1



2





46

1



2




3



4







1x

47





1x



1x



2x

48





2x



1x

49



50

2x
2x





2x

51





1x



1x



1x

52

